

Installation instructions for Boyd Rib FR

**PREPARATION:**

- Remove all wall plates, obstructions and old wallcovering.
- Clean, seal and prime wall before application, especially glossy and semi-gloss paint, wood or concrete walls.
- Seal markings that cannot be removed by cleaning to prevent "bleed-thru".
- Carefully inspect all material before installation.
- Ensure pattern and color is satisfactory and meet specification.

**ADHESIVE APPLICATION:**

- Recommendations of adhesive manufacturer should be strictly followed and take precedence.
- Apply premixed, undiluted, heavy-duty clay based wallcovering adhesive to the wall- NOT THE FABRIC.
- Allow adhesive to become tacky, not dry.
- Care should be taken not to get adhesive on the face. If necessary, check with adhesive manufacture.

**INSTALLATION:**

- For best results, install rolls in numerical sequence by dye lot.
- Cut material to desired lengths; allow minimum 2" on top and bottom for trimming.
- After cutting, installer or distributor assumes all responsibility.
- Acoustical wallcoverings have a nap. Check every roll and cut for nap direction prior to installation. DO NOT ASSUME NAP DIRECTION IS SAME ON ALL ROLLS. DO NOT REVERSE STRIPS; they may appear as a different color or shade.
- Install 3 strips in sequence with nap in same direction.
- Inspect for color, pattern, uniformity and application. If acceptable, proceed with work.
- Continue to inspect in 3 strip intervals. If unacceptable-STOP WORK IMMEDIATELY. Contact your local representative.
- This product is not precision trimmed. Some trimming may be necessary; a straight edge is used to insure an accurate cut.
- Two methods can be used for seaming:  
(1) Overlap and double cut (2) trim edges to a rib and butt seam.
- To insure a good, clean trim, a new blade should be used on each strip.

The above is based upon practical field experience and in no way, expressed or implied, is meant to be a warranty. No claims are allowed for labor. All returns must be made with prior Return Authorization Number, subject to a 30% restocking fee and completed within 30 days of shipping.

For best results, it is recommended that a qualified textile wallcovering installer be employed.

